PH-720B云台使用说明书

1. 云台各部件名称



2. 云台分解名称



以上部件属于可拆装部件

3. 云台细节安装示意图



快装夹座近接示意图，
对着卡槽，锁紧旋钮即可



可滑动至需求位置锁紧



分度云台连接示意图，
对着卡槽，锁紧旋钮即可



可滑动至需求位置锁紧

4. 云台悬臂及反转补地细节安装示意图



旋开如图所示承载板



松开竖板固定旋钮，并移
开竖板



竖板反转180度即可，对
准卡槽



锁紧竖板固定扭即可，如
图所示即可完美补地拍摄。



松开角度固定旋钮，承载板即可每30度
准确进行分度进行拍摄。

分度云台有15度，30度. 45度. 60度. 90度，
五种分度结果进行选择。

中山精格电子科技有限公司
电话： 0760 88361108
网址： www.cavix.cn
地址：中国广东省中山市坦洲镇申塘一路88号

PH-720B Gimbal Head User Manual

Part names





The above parts are removable parts

Details



A diagram of the Snap-fiting
holder connection,Aiming to
the slot,and then lock thek nob.



It could be sl id to the desired
position and lock



A diagram of the Indexing cradle
head connection,Aiming to the
slot,and then lockthe knob.



Slide to the desired posltlon
and lock

Installation



As shown in the figure,Unscrewing
loading board



Loosen the fixing knob of
vertical board



Just flip the vertical board
180 degrees and align the slot



locking the fixing knob of vertical
board,as shown in the figure to fill
the perectshot.



Loosen the fixing knob of rotation,loading board can shoot exactly every 30 degrees.
Indexing cradle head could be adjusted to 15 degrees,30 degrees,45 degrees,60degrees,and 90 degrees

ZhongshanJingge Electronic Technology Co., Ltd.
Tel: +86 (0)760 88361108
URL: www.cavixgear.com